

### PRODUCT INDEX

Our Comprehensive range of Brass and Stainless Steel threaded fittings, adaptors and hose tails are suitable for metal hose, industrial hose and for general purpose piping use.

	Series	Page		Series	Page
	Brass BSPT Male Hose Tail	BR/MT 424		Stainless Steel Hose Joiner	SS/HJ 427
	Brass NPT Male Hose Tail	BR/MN 424		Brass Male x Male Adaptors BSPT x BSPP 60° Coned Seat	BR/A 427
	Brass Male BSPP Hose Tail	BR/MP 424		Brass Male x Male Adaptors BSPP x BSPP 60° Coned Seat	BR/AH 428
	Brass Female BSPP Swivel Hose Tail 60° Coned Seat	BR/FC 424		Brass Female x Female Fixed BSPP Socket	BR/WP 428
	Brass Female BSPP 90° Hose Tail Swept 60° Coned Seat	BR/FS 424		Brass Male x Female Adaptors BSPT x Fixed Female BSPP	BR/AQPT 428
	Brass Female Flatface BSPP Hose Tail	BR/FF 425		Brass Male x Male BSPP Bulkhead Adaptor	BR/B 428
	Brass Male BSPT Swept 90° Hose Tail	BR/MS 425		Brass Male x Male Adaptors NPT x NPT	BR/AN 429
	Brass Male BSPT 90° Hose Tail Compact Elbow	BR/ME 425		Brass Male x Male Adaptors BSPT x BSPT	BR/D 429
	Double Check Valve Right Handed Thread Female	BDC/OXY 425		Brass Male x Male Adaptors BSPT x NPT	BR/DN 429
	Double Check Valve Left Handed Thread Female	BDC/ACT 425			
	Oxygen Right Handed Thread Female Nut & Tail	BRH/OXY 425			
	Acetylene Left Handed Thread Female Nut & Tail	BLH/ACT 425			
	Brass Female BSPT 90° Hose Tail Fixed Elbow	BR/FE 425			
	Brass Hose Joiner	BR/HJ 426			
	Brass Y Hose Tail 3 Way Connector	BR/Y 426			
	Brass Tee Hose Tail 3 Way Tee Connector	BR/T 426			
	Brass Cross Hose Tail 4 Way Connector	BR/CR 426			
	Nickel Plated Brass BSPT Male Hose Tail	NP/MT 426			
	Stainless Steel Female BSPP Swivel Hose Tail 60° Coned Seat	SS/FC 426			
	Stainless Steel BSPT Male Hose Tail	SS/MT 427			

**Brass BSPT Male Hose Tail**



Part Number	Thread 1 (inch)	Hose Tail (inch)
BR/MT-02-02	1/8	1/8
BR/MT-02-03	1/8	3/16
BR/MT-02-04	1/8	1/4
BR/MT-02-05	1/8	5/16
BR/MT-02-06	1/8	3/8
BR/MT-04-02	1/4	1/8
BR/MT-04-03	1/4	3/16
BR/MT-04-04	1/4	1/4
BR/MT-04-05	1/4	5/16
BR/MT-04-06	1/4	3/8
BR/MT-04-08	1/4	1/2
BR/MT-06-04	3/8	1/4
BR/MT-06-05	3/8	5/16
BR/MT-06-06	3/8	3/8
BR/MT-06-08	3/8	1/2
BR/MT-06-10	3/8	5/8
BR/MT-06-12	3/8	3/4
BR/MT-08-04	1/2	1/4
BR/MT-08-05	1/2	5/16
BR/MT-08-06	1/2	3/8
BR/MT-08-08	1/2	1/2
BR/MT-08-10	1/2	5/8
BR/MT-08-12	1/2	3/4
BR/MT-08-16	1/2	1
BR/MT-12-06	3/4	3/8
BR/MT-12-08	3/4	1/2
BR/MT-12-10	3/4	5/8
BR/MT-12-12	3/4	3/4
BR/MT-12-16	3/4	1
BR/MT-16-08	1	1/2
BR/MT-16-10	1	5/8
BR/MT-16-12	1	3/4
BR/MT-16-16	1	1
BR/MT-16-20	1	1 1/4
BR/MT-20-16	1 1/4	1
BR/MT-20-20	1 1/4	1 1/4
BR/MT-24-24	1 1/2	1 1/2
BR/MT-32-32	2	2

**Brass Male BSPP Hose Tail**



Part Number	Thread 1 (inch)	Hose Tail (inch)
BR/MP-04-04	1/4	1/4
BR/MP-06-06	3/8	3/8
BR/MP-08-08	1/2	1/2
BR/MP-12-12	3/4	3/4
BR/MP-16-16	1	1
BR/MP-20-20	1 1/4	1 1/4
BR/MP-24-24	1 1/2	1 1/2
BR/MP-32-32	2	2

**Brass Female BSPP Swivel Hose Tail 60° Coned Seat**



Part Number	Thread 1 (inch)	Hose Tail (inch)
BR/FC-02-02	1/8	1/8
BR/FC-02-03	1/8	3/16
BR/FC-02-04	1/8	1/4
BR/FC-04-03	1/4	3/16
BR/FC-04-04	1/4	1/4
BR/FC-04-05	1/4	5/16
BR/FC-04-06	1/4	3/8
BR/FC-06-04	3/8	1/4
BR/FC-06-05	3/8	5/16
BR/FC-06-06	3/8	3/8
BR/FC-06-08	3/8	1/2
BR/FC-08-05	1/2	5/16
BR/FC-08-06	1/2	3/8
BR/FC-08-08	1/2	1/2
BR/FC-08-10	1/2	5/8
BR/FC-12-08	3/4	1/2
BR/FC-12-10	3/4	5/8
BR/FC-12-12	3/4	3/4
BR/FC-16-08	1	1/2
BR/FC-16-10	1	5/8
BR/FC-16-12	1	3/4
BR/FC-16-16	1	1
BR/FC-20-20	1 1/4	1 1/4
BR/FC-24-24	1 1/2	1 1/2
BR/FC-32-32	2	2

**Brass NPT Male Hose Tail**



Part Number	Thread 1 (inch)	Hose Tail (inch)
BR/MN-02-02	1/8	1/8
BR/MN-02-03	1/8	3/16
BR/MN-02-04	1/8	1/4
BR/MN-04-03	1/4	3/16
BR/MN-04-04	1/4	1/4
BR/MN-04-05	1/4	5/16
BR/MN-04-06	1/4	3/8
BR/MN-06-04	3/8	1/4
BR/MN-06-05	3/8	5/16
BR/MN-06-06	3/8	3/8
BR/MN-08-06	1/2	3/8
BR/MN-08-08	1/2	1/2

**Brass Female BSPP 90° Hose Tail Swept 60° Coned Seat**



Part Number	Thread 1 (inch)	Hose Tail (inch)
BR/FS-02-04	1/8	1/4
BR/FS-04-03	1/4	3/16
BR/FS-04-04	1/4	1/4
BR/FS-04-05	1/4	5/16
BR/FS-04-06	1/4	3/8
BR/FS-06-04	3/8	1/4
BR/FS-06-05	3/8	5/16
BR/FS-06-06	3/8	3/8
BR/FS-08-06	1/2	3/8
BR/FS-08-08	1/2	1/2

3.  
12

## BRASS AND STAINLESS STEEL HOSE COUPLINGS

### Brass Female Flatface BSPP Hose Tail

Part Number	Thread 1 (inch)	Hose Tail (inch)
<b>BR/FF-02-02</b>	1/8	1/8
<b>BR/FF-02-03</b>	1/8	3/16
<b>BR/FF-02-04</b>	1/8	1/4
<b>BR/FF-04-03</b>	1/4	3/16
<b>BR/FF-04-04</b>	1/4	1/4
<b>BR/FF-04-05</b>	1/4	5/16
<b>BR/FF-04-06</b>	1/4	3/8
<b>BR/FF-06-04</b>	3/8	1/4
<b>BR/FF-06-05</b>	3/8	5/16
<b>BR/FF-06-06</b>	3/8	3/8
<b>BR/FF-06-08</b>	3/8	1/2
<b>BR/FF-08-05</b>	1/2	5/16
<b>BR/FF-08-06</b>	1/2	3/8
<b>BR/FF-08-08</b>	1/2	1/2
<b>BR/FF-08-10</b>	1/2	5/8
<b>BR/FF-12-08</b>	3/4	1/2
<b>BR/FF-12-10</b>	3/4	5/8
<b>BR/FF-12-12</b>	3/4	3/4
<b>BR/FF-16-16</b>	1	1
<b>BR/FF-20-20</b>	1 1/4	1 1/4
<b>BR/FF-24-24</b>	1 1/2	1 1/2
<b>BR/FF-32-32</b>	2	2



### Double Check Valve Right Handed Thread Female

Part Number	Thread 1 (inch)	Hose Tail (inch)
<b>BDC/OXY-04-04</b>	1/4	1/4
<b>BDC/OXY-06-04</b>	3/8	1/4
<b>BDC/OXY-06-05</b>	3/8	5/16
<b>BDC/OXY-06-06</b>	3/8	3/8



### Double Check Valve Left Handed Thread Female

Part Number	Thread 1 (inch)	Hose Tail (inch)
<b>BDC/ACT-04-04</b>	1/4	1/4
<b>BDC/ACT-06-04</b>	3/8	1/4
<b>BDC/ACT-06-05</b>	3/8	5/16
<b>BDC/ACT-06-06</b>	3/8	3/8



### Oxygen Right Handed Thread Female Nut & Tail

Part Number	Thread 1 (inch)	Hose Tail (inch)
<b>BRH/OXY-04-04</b>	1/4	1/4
<b>BRH/OXY-06-04</b>	3/8	1/4
<b>BRH/OXY-06-05</b>	3/8	5/16
<b>BRH/OXY-06-06</b>	3/8	3/8



### Acetylene Left Handed Thread Female Nut & Tail

Part Number	Thread 1 (inch)	Hose Tail (inch)
<b>BLH/ACT-04-04</b>	1/4	1/4
<b>BLH/ACT-06-04</b>	3/8	1/4
<b>BLH/ACT-06-05</b>	3/8	5/16
<b>BLH/ACT-06-06</b>	3/8	3/8



### Brass Male BSPT Swept 90° Hose Tail

Part Number	Thread 1 (inch)	Hose Tail (inch)
<b>BR/MS-02-05</b>	1/8	5/16
<b>BR/MS-04-04</b>	1/4	1/4
<b>BR/MS-04-05</b>	1/4	5/16
<b>BR/MS-04-06</b>	1/4	3/8
<b>BR/MS-06-05</b>	3/8	5/16
<b>BR/MS-06-06</b>	3/8	3/8



### Brass Male BSPT 90° Hose Tail Compact Elbow

Part Number	Thread 1 (inch)	Hose Tail (inch)
<b>BR/ME-02-04</b>	1/8	1/4
<b>BR/ME-02-05</b>	1/8	5/16
<b>BR/ME-02-06</b>	1/8	3/8
<b>BR/ME-04-04</b>	1/4	1/4
<b>BR/ME-04-05</b>	1/4	5/16
<b>BR/ME-04-06</b>	1/4	3/8
<b>BR/ME-04-08</b>	1/4	1/2
<b>BR/ME-06-04</b>	3/8	1/4
<b>BR/ME-06-05</b>	3/8	5/16
<b>BR/ME-06-06</b>	3/8	3/8
<b>BR/ME-06-08</b>	3/8	1/2
<b>BR/ME-08-05</b>	1/2	5/16
<b>BR/ME-08-06</b>	1/2	3/8
<b>BR/ME-08-08</b>	1/2	1/2



### Brass Female BSPT 90° Hose Tail Fixed Elbow

Part Number	Thread 1 (inch)	Hose Tail (inch)
<b>BR/FE-04-05</b>	1/4	5/16
<b>BR/FE-04-06</b>	1/4	3/8
<b>BR/FE-06-06</b>	3/8	3/8
<b>BR/FE-06-08</b>	3/8	1/2



**Brass Hose Joiner**



Part Number	Hose Tail (inch)
<b>BR/HJ-02-02</b>	1/8
<b>BR/HJ-03-03</b>	3/16
<b>BR/HJ-04-04</b>	1/4
<b>BR/HJ-05-05</b>	5/16
<b>BR/HJ-06-06</b>	3/8
<b>BR/HJ-08-08</b>	1/2
<b>BR/HJ-10-10</b>	5/8
<b>BR/HJ-12-12</b>	3/4
<b>BR/HJ-16-16</b>	1

**Brass Y Hose Tail 3 Way Connector**



Part Number	Hose Tail (inch)
<b>BR/Y-04-04-04</b>	1/4
<b>BR/Y-05-05-05</b>	5/16
<b>BR/Y-06-06-06</b>	3/8
<b>BR/Y-08-08-08</b>	1/2

**Brass Tee Hose Tail 3 Way Tee Connector**



Part Number	Hose Tail (inch)
<b>BR/T-03-03-03</b>	3/16
<b>BR/T-04-04-04</b>	1/4
<b>BR/T-05-05-05</b>	5/16
<b>BR/T-06-06-06</b>	3/8
<b>BR/T-08-08-08</b>	1/2

**Brass Cross Hose Tail 4 Way Connector**



Part Number	Hose Tail (inch)
<b>BR/CR-03-03-03-03</b>	3/16
<b>BR/CR-04-04-04-04</b>	1/4
<b>BR/CR-05-05-05-05</b>	5/16
<b>BR/CR-06-06-06-06</b>	3/8
<b>BR/CR-08-08-08-08</b>	1/2

**Nickel Plated Brass BSPT Male Hose Tail**



Part Number	Thread 1 (inch)	Hose Tail (inch)
<b>NP/MT-02-02</b>	1/8	1/8
<b>NP/MT-02-03</b>	1/8	3/16
<b>NP/MT-02-04</b>	1/8	1/4
<b>NP/MT-02-05</b>	1/8	5/16
<b>NP/MT-02-06</b>	1/8	3/8
<b>NP/MT-04-02</b>	1/4	1/8
<b>NP/MT-04-03</b>	1/4	3/16
<b>NP/MT-04-04</b>	1/4	1/4
<b>NP/MT-04-05</b>	1/4	5/16
<b>NP/MT-04-06</b>	1/4	3/8
<b>NP/MT-04-08</b>	1/4	1/2
<b>NP/MT-06-04</b>	3/8	1/4
<b>NP/MT-06-05</b>	3/8	5/16
<b>NP/MT-06-06</b>	3/8	3/8
<b>NP/MT-06-08</b>	3/8	1/2
<b>NP/MT-06-10</b>	3/8	5/8
<b>NP/MT-06-12</b>	3/8	3/4
<b>NP/MT-08-04</b>	1/2	1/4
<b>NP/MT-08-05</b>	1/2	5/16
<b>NP/MT-08-06</b>	1/2	3/8
<b>NP/MT-08-08</b>	1/2	1/2
<b>NP/MT-08-10</b>	1/2	5/8
<b>NP/MT-08-12</b>	1/2	3/4
<b>NP/MT-08-16</b>	1/2	1
<b>NP/MT-12-06</b>	3/4	3/8
<b>NP/MT-12-08</b>	3/4	1/2
<b>NP/MT-12-10</b>	3/4	5/8
<b>NP/MT-12-12</b>	3/4	3/4
<b>NP/MT-12-16</b>	3/4	1
<b>NP/MT-16-08</b>	1	1/2
<b>NP/MT-16-10</b>	1	5/8
<b>NP/MT-16-12</b>	1	3/4
<b>NP/MT-16-16</b>	1	1
<b>NP/MT-16-20</b>	1	1 1/4
<b>NP/MT-20-16</b>	1 1/4	1
<b>NP/MT-20-20</b>	1 1/4	1 1/4
<b>NP/MT-24-24</b>	1 1/2	1 1/2
<b>NP/MT-32-32</b>	2	2

**Stainless Steel Female BSPP Swivel Hose Tail 60° Coned Seat**



Part Number	Thread 1 (inch)	Hose Tail (inch)
<b>SS/FC-02-02</b>	1/8	1/8
<b>SS/FC-04-03</b>	1/4	3/16
<b>SS/FC-04-04</b>	1/4	1/4
<b>SS/FC-04-05</b>	1/4	5/16
<b>SS/FC-04-06</b>	1/4	3/8
<b>SS/FC-06-04</b>	3/8	1/4
<b>SS/FC-06-05</b>	3/8	5/16
<b>SS/FC-06-06</b>	3/8	3/8
<b>SS/FC-06-08</b>	3/8	1/2
<b>SS/FC-08-05</b>	1/2	5/16
<b>SS/FC-08-06</b>	1/2	3/8
<b>SS/FC-08-08</b>	1/2	1/2
<b>SS/FC-12-08</b>	3/4	1/2
<b>SS/FC-12-12</b>	3/4	3/4
<b>SS/FC-16-08</b>	1	1/2
<b>SS/FC-16-12</b>	1	3/4
<b>SS/FC-16-16</b>	1	1
<b>SS/FC-20-20</b>	1 1/4	1 1/4
<b>SS/FC-24-24</b>	1 1/2	1 1/2
<b>SS/FC-32-32</b>	2	2

## BRASS AND STAINLESS STEEL HOSE COUPLINGS

### Stainless Steel BSPT Male Hose Tail

Part Number	Thread 1 (inch)	Hose Tail (inch)
SS/MT-02-02	1/8	1/8
SS/MT-02-03	1/8	3/16
SS/MT-02-04	1/8	1/4
SS/MT-02-05	1/8	5/16
SS/MT-02-06	1/8	3/8
SS/MT-04-02	1/4	1/8
SS/MT-04-03	1/4	3/16
SS/MT-04-04	1/4	1/4
SS/MT-04-05	1/4	5/16
SS/MT-04-06	1/4	3/8
SS/MT-04-08	1/4	1/2
SS/MT-06-04	3/8	1/4
SS/MT-06-05	3/8	5/16
SS/MT-06-06	3/8	3/8
SS/MT-06-08	3/8	1/2
SS/MT-06-10	3/8	5/8
SS/MT-06-12	3/8	3/4
SS/MT-08-04	1/2	1/4
SS/MT-08-05	1/2	5/16
SS/MT-08-06	1/2	3/8
SS/MT-08-08	1/2	1/2
SS/MT-08-10	1/2	5/8
SS/MT-08-12	1/2	3/4
SS/MT-08-16	1/2	1
SS/MT-12-06	3/4	3/8
SS/MT-12-08	3/4	1/2
SS/MT-12-10	3/4	5/8
SS/MT-12-12	3/4	3/4
SS/MT-12-16	3/4	1
SS/MT-16-08	1	1/2
SS/MT-16-10	1	5/8
SS/MT-16-12	1	3/4
SS/MT-16-16	1	1
SS/MT-16-20	1	1 1/4
SS/MT-20-16	1 1/4	1
SS/MT-20-20	1 1/4	1 1/4
SS/MT-24-24	1 1/2	1 1/2
SS/MT-32-32	2	2
SS/MT-40-40	2 1/2	2 1/2
SS/MT-48-48	3	3
SS/MT-64-64	4	4



### Brass Male x Male Adaptors BSPT x BSPP 60° Coned Seat

Part Number	Thread 1 (inch)	Thread 2 (inch)
BR/A-02-02	1/8	1/8
BR/A-02-04	1/8	1/4
BR/A-02-06	1/8	3/8
BR/A-02-08	1/8	1/2
BR/A-04-02	1/4	1/8
BR/A-04-04	1/4	1/4
BR/A-04-06	1/4	3/8
BR/A-04-08	1/4	1/2
BR/A-04-12	1/4	3/4
BR/A-06-02	3/8	1/8
BR/A-06-06	3/8	3/8
BR/A-06-08	3/8	1/2
BR/A-06-10	3/8	5/8
BR/A-06-12	3/8	3/4
BR/A-06-16	3/8	1
BR/A-08-04	1/2	1/4
BR/A-08-06	1/2	3/8
BR/A-08-08	1/2	1/2
BR/A-08-10	1/2	5/8
BR/A-08-12	1/2	3/4
BR/A-08-16	1/2	1
BR/A-08-20	1/2	1 1/4
BR/A-10-06	5/8	3/8
BR/A-10-08	5/8	1/2
BR/A-10-10	5/8	5/8
BR/A-10-12	5/8	3/4
BR/A-12-04	3/4	1/4
BR/A-12-06	3/4	3/8
BR/A-12-08	3/4	1/2
BR/A-12-10	3/4	5/8
BR/A-12-12	3/4	3/4
BR/A-12-16	3/4	1
BR/A-12-20	3/4	1 1/4
BR/A-12-24	3/4	1 1/2
BR/A-16-06	1	3/8
BR/A-16-08	1	1/2
BR/A-16-12	1	3/4
BR/A-16-16	1	1
BR/A-16-20	1	1 1/4
BR/A-16-24	1	1 1/2
BR/A-16-32	1	2
BR/A-20-12	1 1/4	3/4
BR/A-20-16	1 1/4	1
BR/A-20-20	1 1/4	1 1/4
BR/A-20-24	1 1/4	1 1/2
BR/A-20-32	1 1/4	2
BR/A-24-16	1 1/2	1
BR/A-24-20	1 1/2	1 1/4
BR/A-24-24	1 1/2	1 1/2
BR/A-24-32	1 1/2	2
BR/A-32-16	2	1
BR/A-32-20	2	1 1/4
BR/A-32-24	2	1 1/2
BR/A-32-32	2	2
BR/A-32-40	2	2 1/2
BR/A-32-48	2	3
BR/A-40-40	2 1/2	2 1/2
BR/A-40-32	2 1/2	2
BR/A-40-48	2 1/2	3
BR/A-48-48	3	3



### Stainless Steel Hose Joiner

Part Number	Hose Tail (inch)
SS/HJ-02-02	1/8
SS/HJ-03-03	3/16
SS/HJ-04-04	1/4
SS/HJ-05-05	5/16
SS/HJ-06-06	3/8
SS/HJ-08-08	1/2
SS/HJ-10-10	5/8
SS/HJ-12-12	3/4
SS/HJ-16-16	1



**Brass Male x Male Adaptors BSPP x BSPP 60° Coned Seat**



Part Number	Thread 1 (inch)	Thread 2 (inch)
BR/AH-02-02	1/8	1/8
BR/AH-04-02	1/4	1/8
BR/AH-04-04	1/4	1/4
BR/AH-06-02	3/8	1/8
BR/AH-06-04	3/8	1/4
BR/AH-06-06	3/8	3/8
BR/AH-08-02	1/2	1/8
BR/AH-08-04	1/2	1/4
BR/AH-08-06	1/2	3/8
BR/AH-08-08	1/2	1/2
BR/AH-10-04	5/8	1/4
BR/AH-10-06	5/8	3/8
BR/AH-10-08	5/8	1/2
BR/AH-10-10	5/8	5/8
BR/AH-12-04	3/4	1/4
BR/AH-12-06	3/4	3/8
BR/AH-12-08	3/4	1/2
BR/AH-12-10	3/4	5/8
BR/AH-12-12	3/4	3/4
BR/AH-16-04	1	1/4
BR/AH-16-06	1	3/8
BR/AH-16-08	1	1/2
BR/AH-16-10	1	5/8
BR/AH-16-12	1	3/4
BR/AH-16-16	1	1
BR/AH-20-04	1 1/4	1/4
BR/AH-20-06	1 1/4	3/8
BR/AH-20-08	1 1/4	1/2
BR/AH-20-10	1 1/4	5/8
BR/AH-20-12	1 1/4	3/4
BR/AH-20-16	1 1/4	1
BR/AH-20-20	1 1/4	1 1/4
BR/AH-24-04	1 1/2	1/4
BR/AH-24-06	1 1/2	3/8
BR/AH-24-08	1 1/2	1/2
BR/AH-24-12	1 1/2	3/4
BR/AH-24-16	1 1/2	1
BR/AH-24-20	1 1/2	1 1/4
BR/AH-24-24	1 1/2	1 1/2
BR/AH-28-24	1 3/4	1 1/2
BR/AH-28-28	1 3/4	1 3/4
BR/AH-32-04	2	1/4
BR/AH-32-08	2	1/2
BR/AH-32-12	2	3/4
BR/AH-32-16	2	1
BR/AH-32-20	2	1 1/4
BR/AH-32-24	2	1 1/2
BR/AH-32-28	2	1 3/4
BR/AH-32-32	2	2
BR/AH-40-20	2 1/2	1 1/4
BR/AH-40-24	2 1/2	1 1/2
BR/AH-40-32	2 1/2	2
BR/AH-40-40	2 1/2	2 1/2
BR/AH-48-32	3	2
BR/AH-48-40	3	2 1/2
BR/AH-48-48	3	3

**Brass Female x Female Fixed BSPP Socket**



Part Number	Thread 1 (inch)	Thread 2 (inch)
BR/WP-02-02	1/8	1/8
BR/WP-02-04	1/8	1/4
BR/WP-04-04	1/4	1/4
BR/WP-04-06	1/4	3/8
BR/WP-04-08	1/4	1/2
BR/WP-06-06	3/8	3/8
BR/WP-06-08	3/8	1/2
BR/WP-08-08	1/2	1/2
BR/WP-08-10	1/2	5/8
BR/WP-08-12	1/2	3/4
BR/WP-10-10	5/8	5/8
BR/WP-12-12	3/4	3/4
BR/WP-12-16	3/4	1
BR/WP-16-16	1	1
BR/WP-20-20	1 1/4	1 1/4
BR/WP-24-24	1 1/2	1 1/2
BR/WP-32-32	2	2

**Brass Male x Female Adaptors BSPT x Fixed Female BSPP**



Part Number	Thread 1 (inch)	Thread 2 (inch)
BR/AQPT-04-02	1/4	1/8
BR/AQPT-04-04	1/4	1/4
BR/AQPT-06-04	3/8	1/4
BR/AQPT-06-06	3/8	3/8
BR/AQPT-08-08	1/2	1/2
BR/AQPT-12-12	3/4	3/4
BR/AQPT-16-16	1	1
BR/AQPT-20-20	1 1/4	1 1/4
BR/AQPT-24-24	1 1/2	1 1/2

**Brass Male x Male BSPP Bulkhead Adaptor**



Part Number	Thread 1 (inch)	Thread 2 (inch)
BR/B-02-02	1/8	1/8
BR/B-02-04	1/8	1/4
BR/B-04-04	1/4	1/4
BR/B-04-06	1/4	3/8
BR/B-04-08	1/4	1/2
BR/B-06-04	3/8	1/4
BR/B-06-06	3/8	3/8
BR/B-06-08	3/8	1/2
BR/B-08-06	1/2	3/8
BR/B-08-08	1/2	1/2
BR/B-08-10	1/2	5/8
BR/B-08-12	1/2	3/4
BR/B-10-10	5/8	5/8
BR/B-12-12	3/4	3/4
BR/B-12-16	3/4	1
BR/B-16-16	1	1
BR/B-20-20	1 1/4	1 1/4
BR/B-24-24	1 1/2	1 1/2
BR/B-32-32	2	2

## BRASS AND STAINLESS STEEL HOSE COUPLINGS

### Brass Male x Male Adaptors NPT x NPT

Part Number	Thread 1 (inch)	Thread 2 (inch)
<b>BR/AN-02-02</b>	1/8	1/8
<b>BR/AN-02-04</b>	1/8	1/4
<b>BR/AN-02-06</b>	1/8	3/8
<b>BR/AN-02-08</b>	1/8	1/2
<b>BR/AN-04-04</b>	1/4	1/4
<b>BR/AN-04-06</b>	1/4	3/8
<b>BR/AN-04-08</b>	1/4	1/2
<b>BR/AN-04-12</b>	1/4	3/4
<b>BR/AN-04-16</b>	1/4	1
<b>BR/AN-06-06</b>	3/8	3/8
<b>BR/AN-06-08</b>	3/8	1/2
<b>BR/AN-06-12</b>	3/8	3/4
<b>BR/AN-08-08</b>	1/2	1/2
<b>BR/AN-08-12</b>	1/2	3/4
<b>BR/AN-08-16</b>	1/2	1
<b>BR/AN-08-20</b>	1/2	1 1/4
<b>BR/AN-08-24</b>	1/2	1 1/2
<b>BR/AN-12-12</b>	3/4	3/4
<b>BR/AN-12-16</b>	3/4	1
<b>BR/AN-12-20</b>	3/4	1 1/4
<b>BR/AN-12-24</b>	3/4	1 1/2
<b>BR/AN-16-16</b>	1	1
<b>BR/AN-16-20</b>	1	1 1/4
<b>BR/AN-16-24</b>	1	1 1/2
<b>BR/AN-20-20</b>	1 1/4	1 1/4
<b>BR/AN-20-24</b>	1 1/4	1 1/2
<b>BR/AN-20-32</b>	1 1/4	2
<b>BR/AN-24-24</b>	1 1/2	1 1/2
<b>BR/AN-24-32</b>	1 1/2	2
<b>BR/AN-32-32</b>	2	2
<b>BR/AN-40-40</b>	2 1/2	2 1/2



### Brass Male x Male Adaptors BSPT x BSPT

Part No	Thread 1 (inch)	Thread 2 (inch)
<b>BR/D-02-02</b>	1/8	1/8
<b>BR/D-02-04</b>	1/8	1/4
<b>BR/D-02-06</b>	1/8	3/8
<b>BR/D-04-04</b>	1/4	1/4
<b>BR/D-04-06</b>	1/4	3/8
<b>BR/D-04-08</b>	1/4	1/2
<b>BR/D-06-06</b>	3/8	3/8
<b>BR/D-06-08</b>	3/8	1/2
<b>BR/D-08-08</b>	1/2	1/2
<b>BR/D-08-12</b>	1/2	3/4
<b>BR/D-10-10</b>	5/8	5/8
<b>BR/D-12-12</b>	3/4	3/4
<b>BR/D-12-16</b>	3/4	1
<b>BR/D-16-16</b>	1	1
<b>BR/D-20-20</b>	1 1/4	1 1/4
<b>BR/D-20-24</b>	1 1/4	1 1/2
<b>BR/D-24-24</b>	1 1/2	1 1/2
<b>BR/D-32-32</b>	2	2
<b>BR/D-40-40</b>	2 1/2	2 1/2
<b>BR/D-48-48</b>	3	3



### Brass Male x Male Adaptors BSPT x NPT

Part Number	Thread 1 (inch)	Thread 2 (inch)
<b>BR/DN-04-04</b>	1/4	1/4
<b>BR/DN-04-06</b>	1/4	3/8
<b>BR/DN-06-06</b>	3/8	3/8
<b>BR/DN-06-04</b>	3/8	1/4
<b>BR/DN-08-08</b>	1/2	1/2
<b>BR/DN-12-12</b>	3/4	3/4
<b>BR/DN-16-16</b>	1	1
<b>BR/DN-20-20</b>	1 1/4	1 1/4
<b>BR/DN-24-24</b>	1 1/2	1 1/2
<b>BR/DN-32-32</b>	2	2

